

Chip Timing System

Instructions for Stage Crews

At Stages 2,3, and 4 the timing boxes will be picked up and packed by Race Central personnel for movement to Stages 18, 19, and 20. **IF one of these stages close before the Race Central personnel arrive at the stage contact Com 1 on the main radio network for instructions on what to do with the chip timing equipment.**

On the timing Controller Box if all **RED** Lights start to come on:

1. Pull out the battery cable
2. On screen press **Messages**
3. Press **OK** until lights stop blinking
4. Press **Done**
5. The controller will continue to run and you can plug the battery back in.

To ready the Chip Timing Equipment for pick up by the equipment truck after the last runner is through the stage.

1. Turn off the controller box by pressing **Status** and then **Shut Down**
2. Lift the middle of the mat, unchannel the cable from the mat antenna
3. Unhook the battery
4. Put antenna, cable, battery cables, in the plastic box that says Race Central.
5. Load mat, controller, battery and plastic box onto the equipment truck.